


**CLUTCH**

**SECTION CL**

[Go to Table of Contents](#)

[Go to Quick Reference Index](#)

## PRECAUTIONS AND PREPARATION



### Precautions

- Recommended fluid is brake fluid “DOT 3”.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.

### WARNING:

After cleaning clutch disc, wipe it with a dust collector. Do not use compressed air.

## Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
GG94310000 ( — ) Flare nut torque wrench	<p>Removing and installing clutch piping</p> <p>NT406</p> <p>a: 10 mm (0.39 in)</p>
KV30101000 (J33213) Clutch aligning bar	<p>Installing clutch cover and clutch disc</p> <p>NT440</p> <p>a: 12 mm (0.47 in) dia. b: 15.7 mm (0.618 in) dia. c: 22.8 mm (0.898 in) dia. d: 21 mm (0.83 in) e: 22 mm (0.87 in)</p>
ST20050240 ( — ) Diaphragm spring adjusting wrench	<p>Adjusting unevenness of diaphragm spring of clutch cover</p> <p>NT404</p> <p>a: 150 mm (5.91 in) b: 25 mm (0.98 in)</p>
KV32101000 (J25689-A) Pin punch	<p>Removing and installing spring pin</p> <p>NT410</p> <p>a: 4 mm (0.16 in) dia.</p>

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING



## NVH Troubleshooting Chart

Use the chart below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, repair or replace these parts.

Reference page			
SUSPECTED PARTS (Possible cause)	CLUTCH PEDAL (Free play out of adjustment)	CL-5	
	CLUTCH LINE (Air in line)	CL-6	
	MASTER CYLINDER PISTON CUP (Damaged)	CL-7	
	OPERATING CYLINDER PISTON CUP (Damaged)	CL-8	
	ENGINE MOUNTING (Loose)	Refer to EM section.	
	RELEASE BEARING (Worn, dirty or damaged)	CL-9	
	CLUTCH DISC (Out of true)	CL-10	
	CLUTCH DISC (Runout is excessive)	CL-10	
	CLUTCH DISC (Lining broken)	CL-10	
	CLUTCH DISC (Dirty or burned)	CL-10	
	CLUTCH DISC (Oily)	CL-10	
	CLUTCH DISC (Worn out)	CL-10	
	CLUTCH DISC (Hardened)	CL-10	
	CLUTCH DISC (Lack of spline grease)	CL-10	
	DIAPHRAGM SPRING (Damaged)	CL-11	
	DIAPHRAGM SPRING (Out of tip alignment)	CL-11	
PRESSURE PLATE (Distortion)	CL-11		
FLYWHEEL (Distortion)	CL-11		
Symptom	Clutch grabs/chatters		
	Clutch pedal spongy		
	Clutch noisy		
	Clutch slips	1	
	Clutch does not disengage	1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
		1	2
	</		

# CLUTCH SYSTEM — Hydraulic Type

SEC. 300-305-306-465




- ① Pedal bracket
- ② Clutch master cylinder
- ③ Clutch interlock switch
- ④ Fulcrum pin
- ⑤ Pin
- ⑥ Clutch pedal
- ⑦ Operating cylinder

- ⑧ Air bleeder screw
- ⑨ Withdrawal lever
- ⑩ Release bearing
- ⑪ Clutch hose
- ⑫ Clutch cover
- ⑬ Clutch disc
- ⑭ Clevis pin

- ⑮ Assist spring
- ⑯ ASCD cancel switch
- ⑰ Washer
- ⑱ Clutch hose connector
- ⑲ Bushing
- ⑳ Stopper rubber

SCL714




## Adjusting Clutch Pedal

1. Adjust pedal height with ASCD cancel switch.

**Pedal height "H":**

**168 - 175 mm (6.61 - 6.89 in)**




2. Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

**Pedal free play "A":**

**9 - 16 mm (0.35 - 0.63 in)**

- Push or step on clutch pedal until resistance is felt, and check the distance the pedal moves.




## For U.S.A. model only

3. Adjust clearance "C" shown in the figure while fully depressing clutch pedal.

**Clearance C:**

**0.3 - 1.0 mm (0.012 - 0.039 in)**



### Bleeding Procedure


1. Bleed air from clutch operating cylinder according to the following procedure.

**Carefully monitor fluid level at master cylinder during bleeding operation.**

- a. Top up reservoir with recommended brake fluid.
  - b. Connect a transparent vinyl tube to air bleeder valve.
  - c. Slowly depress clutch pedal all the way several times.
  - d. With clutch pedal depressed, open bleeder valve to release air. Then close bleeder valve.
  - e. Release clutch pedal and wait for a few seconds.
  - f. Repeat steps c through e above until brake fluid flows from air bleeder valve without air bubbles.
2. Bleed air from clutch piping connector according to the above same procedure.
  3. Repeat the above bleeding procedures 1 and 2 several times.

## Clutch Master Cylinder

SEC. 305



SCL762

### DISASSEMBLY AND ASSEMBLY

- Push piston into cylinder body with screwdriver when removing and installing valve stopper.


### INSPECTION

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

## Operating Cylinder

SEC. 306



: Apply rubber lubricant.

SCL709

### INSPECTION


Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Piston spring, for wear or damage
- Dust cover, for cracks, deformation or damage



# CLUTCH RELEASE MECHANISM


SEC. 321



## INSPECTION

Check the following items, and replace if necessary.

- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting or wear
- Release sleeve and withdrawal lever rubbing surface, for wear, rust or damage




## LUBRICATION


- Apply recommended grease to contact surface and rubbing surface.
- Too much lubricant might damage clutch disc facing.

# CLUTCH DISC AND CLUTCH COVER

## SEC. 300



SCL599-C



## Clutch Disc


### INSPECTION

Check the following items, and replace if necessary.

- Clutch disc, for burns, discoloration, oil or grease leakage
- Clutch disc, for wear of facing

**Wear limit of facing surface to rivet head:**

**0.3 mm (0.012 in)**



- Clutch disc, for spline backlash

**Maximum spline backlash (at outer edge of disc):**

**1.0 mm (0.039 in)**

- Clutch disc, for facing runout

**Runout limit:**


**1.0 mm (0.039 in)**

**Distance of runout check point (from hub center)**

**115 mm (4.53 in)**

### INSTALLATION


- Apply recommended grease to contact surface of spline portion.
- Too much lubricant might damage clutch facing.



## Clutch Cover and Flywheel


### INSPECTION AND ADJUSTMENT

- Check clutch cover installed on vehicle for unevenness of diaphragm spring toe height.  
**Uneven limit:**  
**0.5 mm (0.020 in)**
- If out of limit, adjust the height with Tool.



### FLYWHEEL INSPECTION


- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.
- Check flywheel runout.  
**Maximum allowable runout:**  
**Refer to EM section ("Inspection", "CYLINDER BLOCK").**




### INSTALLATION

- Insert Tool into clutch disc hub when installing clutch cover and disc.
- Tighten bolts in numerical order.
- **Be careful not to allow grease to contaminate clutch facing.**

**First step:**

: 10 - 20 N·m (1 - 2 kg-m, 7 - 14 ft-lb)

**Final step:**

: 34 - 44 N·m (3.5 - 4.5 kg-m, 25 - 33 ft-lb)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### General Specifications

#### CLUTCH CONTROL SYSTEM

Type of clutch control	Hydraulic
------------------------	-----------

#### CLUTCH MASTER CYLINDER

Inner diameter	mm (in)	15.87 (5/8)
----------------	---------	-------------

#### CLUTCH OPERATING CYLINDER

Inner diameter	mm (in)	19.05 (3/4)
----------------	---------	-------------

#### CLUTCH DISC

Unit: mm (in)

Model	240
Facing size (Outer dia. x inner dia. x thickness)	240 x 160 x 3.5 (9.45 x 6.30 x 0.138)
Thickness of disc assembly	
With load	7.6 - 8.0 (0.299 - 0.315) with 5,688 N (580 kg, 1,279 lb)

#### CLUTCH COVER

Model	240
Set load	N (kg, lb) 5,688 (580, 1,279)

### Inspection and Adjustment

#### CLUTCH PEDAL

Unit: mm (in)

Pedal height*	168 - 175 (6.61 - 6.89)
Pedal free play	9 - 16 (0.35 - 0.63)
Clearance between pedal stopper rubber and clutch interlock switch threaded end while clutch pedal is fully depressed.	0.3 - 1.0 (0.012 - 0.039)

\*: Measured from surface of dash reinforcement panel to surface of pedal pad

#### CLUTCH DISC

Unit: mm (in)

Model	240
Wear limit of facing surface to rivet head	0.3 (0.012)
Facing runout limit	1.0 (0.039)
Distance of runout check point (from the hub center)	115 (4.53)
Maximum spline backlash (at outer edge of disc)	1.0 (0.039)

#### CLUTCH COVER

Unit: mm (in)

Model	240
Uneven limit of diaphragm spring toe height	0.5 (0.020)

SECTION **CL****CONTENTS**

<b>PRECAUTIONS AND PREPARATION</b> .....	2	<b>HYDRAULIC CLUTCH CONTROL</b> .....	7
Precautions .....	2	Clutch Master Cylinder .....	7
Special Service Tools .....	2	Operating Cylinder .....	8
<b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>		<b>CLUTCH RELEASE MECHANISM</b> .....	9
<b>TROUBLESHOOTING</b> .....	3	<b>CLUTCH DISC AND CLUTCH COVER</b> .....	10
NVH Troubleshooting Chart.....	3	Clutch Disc.....	10
<b>CLUTCH SYSTEM — Hydraulic Type</b> .....	4	Clutch Cover and Flywheel .....	11
<b>INSPECTION AND ADJUSTMENT</b> .....	5	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	12
Adjusting Clutch Pedal .....	5	General Specifications .....	12
Bleeding Procedure .....	6	Inspection and Adjustment .....	12