
Drg No. E-3R1-01 REMOVE ALL BURRS AND SHARP EDGES.

THIRD ANGLE PROJECTION.




TITLE ASSEMBLY


A1(4)border

Drg. No. E-3R1-01 Quaife Design & Development.

SOLID WORK

REMOVE ALL BURRS AND SHARP EDGES. THIRD ANGLE PROJECTION. Drg No. E-3R1-01





TITLE ASSEMBLY

A1(4)border

Drg. No. E-3R1-01

Quaife Design & Development.

IFEAIMENI.
ISSUE. 01 DATE. 22.7.04
IF IN DOUBT, ASK. DRAWN BY, J.P.D.
Used In. LOTUS ELISE (P.G.1) 5 SPEED C.R.
SYNCHROMESH GEAR KIT